## EXHIBIT 39



### ERX Edge Routers System Basics Configuration Guide



Release 4.0.x

Juniper Networks, Inc. 1194 North Mathilda Avenue Sunnyvale, CA 94089 USA 408-745-2000 www.juniper.net

Part No. 162-00469-02 Rev. A00



# Command Line Interface

2

This chapter provides information about your ERX system's command line interface (CLI).

Page
2-1
2-21
2-22
2-26
2-29

### **Overview**

Managing your system using the CLI gives you access to thousands of commands. The system's CLI uses an industry *de facto* standard look and feel, which may be familiar to you. If you are new to this CLI, it is helpful to read this entire chapter, where you can learn about CLI shortcuts and other helpful information.

#### **Command Modes**

Gommand modes set a context for the GLI. Each command in the GLI is available from one or more command modes. From some command modes you can only view router information; from others you can perform configuration tasks. For example, you can access User Exec mode to display information and then access Global Configuration mode to set parameters or enable a particular feature. By recognizing the command line prompt, you can identify where you are in the GLI at any